puggle



R129/04


Safe Fit i-Size Isofix Rotating Car Seat Base

Everything you need to know

IMPORTANT. READ THESE INSTRUCTIONS AND SAFETY WARNINGS CAREFULLY BEFORE USE, AND KEEP FOR FUTURE REFERENCE.

This Puggle Safe Fit i-Size Isofix Rotating Car Seat Base is tested to comply with R129/04.

Welcome



Thank you for purchasing the Puggle Safe Fit i-Size Isofix Rotating Car Seat Base, we hope you love it as much as we do!

Getting started:

Lay out the parts on a soft, level surface and compare to the part/ fixings checklist.

Do not discard any packaging until you are sure that you have all the parts.

We're here to help!

If you have a query with this product or require replacement parts, please contact us at support@pugglebaby.co.uk.

Learn more

Scan the QR code to view our step-by-step demonstration video.

www.thenurserystore.co.uk

Notice


This is an approved i-Size holding system under the ECE R129 regulation for children between 40 and 87cm and a maximum weight of 13kg, suitable for car seats compatible with "i- Size " as indicated by the vehicle manufacture in the vehicle user's manual.

ONLY use this child restraint system rearward facing.

This is an i-Size Enhanced Child Restraint System. It is approved according to UN Regulation No.129, for use in, i-Size compatible vehicle seating positions as indicated by the vehicle users' manual. If in doubt, consult either the Enhanced Child Restraint System manufacturer or the retailer.

The instruction manual should be kept safely with the child restraint system for its life period.


The car seat must not be used on the position where an airbag has been activated (airbags can be fatal to children).
Please read the instructions carefully to use the child car seat properly.




Ensure that your vehicle has ISOFIX anchor points.

Refer to the vehicle list in this manual for information of where the child car seat base will fit in your vehicle.

Car seat ISOFIX attachment anchor points




Parts List




- A Child car seat base
- B Support leg
- C Support leg adjustment button
- D Support leg indicator
- E 360° rotation button
- F Child car seat release lever
- G Securing Rods
- H ISOFIX Connector
- I ISOFIX release button
- J ISOFIX security indicator


Installation



Unfold the support leg from the under side of the base.




Press and hold the ISOFIX adjustment buttons and extend the ISOFIX connectors fully.




Position the base on the vehicle seat. Slide the two ISOFIX connectors firmly onto the anchor points until the ISOFIX connectors engage with a "click" on both sides and the ISOFIX security indicators have turned green.

CAUTION! The ISOFIX connectors are only correctly engaged if both of the ISOFIX buttons are green.



Push the base back until it rests firmly against the vehicle seat backrest.




Ensure the top of the support leg is out and over the edge of the vehicle car seat.


Press the adjustment button on the support leg, and adjust so that it is in full contact with the ground of the vehicle (the display indicator will turn green when correctly aligned).

IMPORTANT! When the support leg touches the car floor, the indicator MUST be all green.

Fixing Infant Car Seat to the Base




Place the infant car seat on the base and press it down until the securing rods are fully engaged.




The indicators on the two car seat release levers will turn green when the infant car seat is securely fastened.
If the indicators are not GREEN, the infant carrier is NOT sufficiently locked.
If necessary, repeat the procedure, ensuring both levers are GREEN.
Check it is secure by trying to lift of the infant carrier.

Rotating Function



Pull the rotation lever located at the front of the base to rotate the infant car seat from rearward facing position to facing the car door. The lever will show green when clicked into position.


WARNING! Side rotation is only for use for placing the child in, or lifting the child out of the infant car seat. DO NOT rotate the infant carrier when the car is in motion.




Ensure the infant car seat is rotated to rearward facing position and securely locked in place before driving.

IMPORTANT! Before each trip, ensure the infant carrier is locked into position.

Removing the Infant Car Seat






To remove the infant car seat from the base pull either of the car seat release levers and lift the infant car seat off the base.

There is a release lever located at the back of the infant car seat if the seat is still in rearward position.


Or, there is a second release lever located at the front of the infant car seat for when the seat is rotated to the side.

WARNING! DO NOT remove the infant car seat when the car is in motion.

Removing the Base



Press the support leg adjustment button to fully retract the support leg.



Squeeze the ISOFIX release button to disengage the ISOFIX connectors and remove i-size base from the vehicle.

Warnings

WARNING: This child car seat has been approved for transportation in cars of children from birth, height between 40-87cm/≤13 kg.
WARNING: NEVER use this child car seat with its side facing the vehicle seat.
WARNING: Any rigid items and plastic parts of the child car seat must be so located and installed that they are not liable, during everyday use of the vehicle, to become trapped by a movable seat or in a door of vehicle.
WARNING: If any load bearing points other than those described in the instructions are used, this can signifcantly reduce the protection factor of the child car seat.
WARNING: ALWAYS secure your child with the safety Y shape belt when using this child car seat.
WARNING: Never leave your child unattended.
WARNING: Do not attempt to dismantle, modify or add to any part of the child car seat or change the way your vehicle seat belts are made or used.
WARNING: After an accident the child car seat should be replaced and the vehicle seat belts. Although they may look undamaged, they may not protect your child as well as they should.

Warnings

WARNING: Do not place anything such as a towel or cushion under the child car seat. This could affectthe perforrance of the child restraint system in an accident.
WARNING: Always make sure that the child car seat Y shape belt are correctly tensioned to ensure maximurn protection for your child.
WARNING: Prevent Y shape belt from getting trapped between car doors or rubbing against sharp parts of the seat or body.
WARNING: Never use replacernent parts other than those approved by us.
WARNING: We advise that child car seat should not be bought or sold second-hand. Many child car seat acquired this way have been found to be dangerous.
WARNING: The child car seat can mark vehicle seat upholstery. We cannot be held responsible for damage or marking to vehicle seat upholstery.
WARNING: Security is only guaranteed if the child car seat is fitted in accordance with these instructions.
WARNING: Safely secure any luggage or other objects that might cause injuries to the occupant of the child car seat in the event of a collision.

Warnings

WARNING: Failure to comply with the instructions would be dangerous and will automatically void the warranty.
WARNING: The Y shape belt buckle has been designed to be released quickly in an emergency. IT IS NOT CHILD PROOF. More inguisitive children may learn to undo the buckle. Children should be told never to play with the harness buckle or any other part of the child car seat.
WARNING: Never use the child seat without its fabric cover because the fabric cover constitutes as an integral part of the child car seat performance.
WARNING: Cover the child car seat if it is left in direct sun light for prolonged period as the child car seat surfaces may get very hot. Check the child car seat surface before playing your child in the seat.
WARNING: Do not use as a reclined cradle.

Cleaning

Wipe clean using a soft sponge with diluted detergent or water.
Wipe metals and plastic parts with a mild detergent and lukewarm water. DO NOT use chemical cleaners or bleaches (ammonia, petrol, solvents etc.) under any circumstances.

Maintenance

Regularly check all important parts for damage.
Ensure the correct operation of all mechanical components.
To prevent damage or breakage, ensure that the product does not become jammed in the car door, seat, runners, etc.
This type of product requires careful and regular maintenance by the user.
Protect the product from atmospheric agents, water, rain, snow. If necessary, immediately dry all the metal parts in order to avoid the formation of rust.
DO NOT store the product if it is wet. DO NOT leave in humid environments.
Gradual wear of plastic, for example caused by exposure to sunlight (UV), can cause a slight deterioration of product properties. Since very high temperature fluctuations and other unpredictable stresses are common in vehicles, the following points must be observed:
If the vehicle is directly exposed to strong sunlight for long periods, the child car seat must be removed from the vehicle or covered with a light cloth.

Troubleshooting

Issue	Solution
Base wobbles or feels loose	Check the support leg. The support leg must be firmly on the floor, not hovering. Adjust the height until the indicator turns green.
Base will not connect to the ISOFIX anchor points	Ensure there are no seat covers, debris, or fabric blocking the ISOFIX anchor points in the car seat crease. Ensure both ISOFIX arms are extended equally and aligned straight with the car's anchorage points. especially after snacks or travel.
Infant car seat will not release from the base	Locate the release button and ensure it is fully engaged. If the seat is stuck to the base, it is often easier to remove the entire base from the car first, allowing you to get a better angle on the release mechanism.

For any and all other product issues not covered in the above please contact our dedicated customer services team
Contact: support@pugglebaby.co.uk

Recycling the Packaging

When you have unpacked your product and ensured that all parts are present, please discard the packaging components in accordance with your local
authority guidelines. For further information, please check the material and your postcode at

https://www.recyclenow.com/recycle-an-item.

Notes

Notes

www.thenurserystore.co.uk

Imported by Online4baby Ltd.
Meadowbank, Tweedale Way, Oldham, OL9 8EH