
puggle




Easy Spin 6 in 1 Trike

Everything you need to know

IMPORTANT. RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

CAUTION: There are many small components used in the construction of this Trike. These items should be kept out of reach of young children whilst assembling the unit.

This Puggle Easy Spin 6 in 1 Trike is tested to comply with EN 71-1



Thank you for purchasing the Easy Spin 6 in 1 Trike, we hope you love it as much as we do!

Getting started:

- The Easy Spin 6 in 1 Trike should be assembled on a clean surface, free from any sharp objects that could mark or damage the product.
- Discard packaging in accordance with your local authority guidelines.
- Do not discard any packaging until you are sure that you have all the parts.

We're here to help!


If you have a query with this product or require replacement parts, please contact us at **support@pugglebaby.co.uk**.

Learn more


Scan the QR code to view our step-by-step instructional video.

www.thenurserystore.co.uk

Parts list




- A Rear wheels x2
- B Trike Frame
- C Front wheel
- D Mudguard
- E Handlebar
- F Steering post
- G Steering rod
- H Seat platform
- I Seat unit
- J Seat adjustment knob
- K Canopy
- L Allen key/cross-head screwdriver
- M Spanner
- N Bumper bar parts x 2
- O Basket
- P Small attachment knob
- Q Steering handle




*parts not visible on this diagram have not been labelled

1



Remove protective cap from rear wheel


2



Insert rear wheel axles into the frame


Assembling the front wheel mudguard

3



Remove protective cap from the front wheel post


4



Slide mudguard onto front wheel post

Assembling the front wheel mudguard


5



Insert the front wheel tubing through the front post of the trike frame


Assembling the handlebar

6




Insert the handlebar through the trike frame and onto the front wheel tubing

7



To change between steering and non-steering modes, push the rectangular button


8



To fold the handlebar, push the circular button


Assembling the steering post

9




Remove the cap from the bottom of the steering post using a cross head screwdriver


10



Insert the steering post into the tube at the back of the trike frame

11






Replace the cap and tighten the screw using cross head screwdriver


Assembling the steering rod

13




Insert front of steering rod into hole in mudguard

14



Rotate steering rod backwards until horizontal

15




Insert back end of steering rod into hole on the arm of the steering post from the bottom.

Secure with nut provided

Use spanner to tighten


Assembling the seat

16




Squeeze adjuster on back of seat unit to unfold

17




Align hole on the seat platform with the seat tube on trike frame

18




Seat platform should be horizontal when placed on frame

19




Insert fitting on underside of seat into hole on top of seat platform

20



Secure seat with seat adjustment knob


21



Install canopy by sliding the attachment points onto the seat unit


Assembling the bumper bar

22



Insert end of bumper bar into bracket on side of seat unit


23



Connect bumper bar in the centre until button clicks into place


Assembling basket/parent steering handle

24



Slot basket onto back post of trike frame


25



Secure basket with small attchment knob


WARNING! This steering handle is designed to guide/push the trike on even surfaces. Do NOT use the steering handle to lift the trike over steps or kerbs.

26



Slide steering handle onto steering post until it clicks into place


27



Secure by rotating lever upwards and snapping into place


Adjusting the canopy

28



To fully extend canopy, pull both canopy bars in opposite directions until you hear a click


29



Canopy can be tilted forwards or backwards using rear canopy bar


Adjusting the footrest

29



Pull both footplates open

30




Pull collar down on footrest tubing to release and rotate down

Reverse process to fold footrest


Adjusting the seat

31




To rotate or move seat, loosen seat adjustment knob

32



Rotate seat unit to desired direction

33




Slide seat unit forward or backward to desired position

Child should be able to reach pedals or footrest

Always tighten adjustment knob fully after adjusting

Reclining the seat

34



Squeeze adjuster on back of seat to adjust recline or fold seat unit


35



Choose desired position and release adjuster, seat unit will click into place


Adjusting/removing the steering handle

36



Press spring pins in tubing of steering handle to move between 3 height positions

37




To remove steering handle unclip latch and rotate until it presses spring pin to release handle

NOTE: This trike is designed for use on flat, smooth surfaces only. It is not intended to be ridden or pushed over curbs, steps, or other uneven obstacles

Using the brakes

38




NOTE: There are TWO brakes

One on each rear wheel

The brakes operate seperately, be sure to engage BOTH sides

39




To apply brakes, push down firmly on each pedal with your foot

40

To release brakes, place your toes under each pedal and push upwards


Opening/removing the bumper bar

41



To open bumper bar, press button in the centre and swing both sides outwards


42



To remove bumper bar, press buttons on either side of seat unit and pull


Removing the wheels/ seat back

43




To remove rear wheels for cleaning or storage, press metal button on top of wheel housing

44



To remove back of seat unit for older children, remove covers and harness then press buttons on either side of seat unit

45



Lift the seat back from the seat base

Warnings

- **WARNING:** A child's safety is your responsibility.
- **WARNING:** Adult assembly is required.
- **WARNING:** Ensure that all components are fitted securely into place and tightened where applicable before allowing your child to play with the 6 in 1 trike.
- **WARNING:** Ensure that the child is supervised by an adult when using the 6 in 1 trike at all times, and is taught about the correct usage of the product.
- **WARNING:** Ensure that all locking devices are engaged before usage.
- **WARNING:** This product is suitable for use by one child at a time only.
- **WARNING:** DO NOT overload this product, maximum capacity is 25kg. Approximate age range is 9 months to 5 years.
- **WARNING:** Keep hands and other limbs away from moving parts such as the wheel to prevent entrapment and injury.
- **WARNING:** Protective equipment should be worn. Children should wear approved protective equipment e.g. helmet and correct fitting is required.
- **WARNING:** DO NOT allow a child to ride on roadways, public highways or alleys. Not to be used in traffic.
- **WARNING:** DO NOT allow a child to ride on steeply sloped areas, near steps, swimming pools, or other bodies of water.
- For use on smooth, paved surfaces only.
- Ensure that the rider keeps both hands on the handlebar at all time for proper control.
- **WARNING:** DO NOT allow a child to ride the product at dusk, at night or at times of limited visibility.
- Children should be reminded that the toy should be used with caution, since it requires skill, so as to avoid falls or collision causing injury to the user and third parties. They should also be reminded of the dangers of using this product on public highways.
- **WARNING!** This steering handle is designed to guide/push the trike on even surfaces. Do NOT use the steering handle to lift the trike over steps or kerbs.
- All assembly fittings should always be tightened properly, checked periodically and the care should be taken that no bolts are loose, because a child could trap parts of the body or clothing (e.g. strings, necklaces, ribbons for babies' dummies), which could pose a risk of suffocation and strangulation.

- Bags and other items should not be hung from the handles as this can affect the stability of the product.
- DO NOT use parts or accessories which are not approved or supplied by the manufacturer.
- DO NOT allow your child to play with this product without adult supervision.
- Ensure that the basket is emptied and any accessories are removed prior to folding.
- A basket is provided for the carriage of items evenly distributed upto a maximum of 2kg.
- Overloading, incorrect folding and the use of non-approved accessories is unsafe and may damage or break this product.
- If a raincover is supplied, do not leave the raincover on indoors, in a hot atmosphere or near a heat source as your child may overheat.
- To prevent damage, remove the raincover before folding.
- Do not place anything on top of the raincover.
- **NOTE: This trike is designed for use on flat, smooth surfaces only. It is not intended to be ridden or pushed over curbs, steps, or other uneven obstacles**

Symbol	Meaning
CE	European conformity – This mark is applied to both physical product and product packaging, indicating conformity with the relevant European testing standards.
UK CA	UK Conformity Assessed – This mark is applied to both physical product and product packaging, indicating conformity with the relevant UKSI testing standards.

Issue	Solution
Missing parts	The fittings for this product are supplied inside a bag within the main carton. Check all the packaging thoroughly to ensure that you have not overlooked them before you throw it away. If necessary, contact our customer service team at support@pugglebaby.co.uk.

For any and all other product issues not covered in the above please contact our dedicated customer services team
Contact: support@pugglebaby.co.uk

Recycling the Packaging

When you have unpacked your product and ensured that all parts are present, please discard the packaging components in accordance with your local authority guidelines. For further information, please check the material and your postcode at

https://www.recyclenow.com/recycle-an-item.

Notes

www.thenurserystore.co.uk

Imported by Online4baby Ltd.
Meadowbank, Tweedale Way, Oldham, OL9 8EH