
puggle




Splashy Bath, Storage & Changing Unit

Everything you need to know

IMPORTANT. RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

CAUTION: There are many small components used in the construction of this bath, storage and changing unit. These items should be kept out of reach of young children whilst assembling the unit.

This Puggle Splashy Bath, Storage & Changing Unit is tested to comply with EN 12221-1 & -2:2008 + A1:2013



Thank you for purchasing the Splashy Bath, Storage & Changing Unit, we hope you love it as much as we do!

Getting started:

Lay out the parts on a soft, level surface and compare to the part/ fixings checklist.

Do not discard any packaging until you are sure that you have all the parts.

We're here to help!


If you have a query with this product or require replacement parts, please contact us at supp**ort@pugglebaby.co.uk**.

Learn more

Scan the QR code to view our step-by-step demonstration video.


www.thenurserystore.co.uk

Parts List



- A Side panel
- B Changing mat
- C Bath
- D Support frame
- E Mat rack
- F Small panel
- G Pan trays
- H Utility holder a
- I Utility holder b
- J Wash bowl
- K Towel rail
- L Base shelf
- M Castors
- N Bath plug
- O Drain hose
- P Nut
- Q Spanner


Parts List



*parts not visible on this diagram have not been labelled


Assembly

1




Install four casters to the bottom of the side panels.

2




On the side panels, rotate the steel tubes 90° and insert the smaller diameter tube into the socketed end of the other tube along the same straight line.

3




Align the support frames with the side panels and push them down to the bottom of the structure. Ensure the tubes are inserted through the plastic brackets.

4




Flip the main structure and secure a plastic nut onto a plastic bolt and tighten using the spanner.

5




Place the remaining nuts (P) onto the plastic bolts in sequence and tighten them. Press down on the pedal to engage the castor lock. Push the pedal upwards to disengage the lock.
WARNING: Ensure the castors are locked when using the changer.

6




Align the small panels with the pre-existing slots on the support frames and push them down to secure.

7




Place the base shelf within the small panels at the bottom of the unit and press down firmly until they "snap" securely in place.

8




Place the two pan trays onto the assembled support frames, aligning their slots with the tubes.

9




Place the two utility holders onto the top steel tubes in sequence, aligning their slots with the tubes.

10




Insert the drainage hose into the outlet on the underside of the bath.

11




Place the bath on top and insert the bath plug.
WARNING: Before placing water in the bath ensure the bath plug is firmly inserted in the plug hole on the inside of the bath.

12




Remove the anti-closure safety covers from the mat rack.

13




On the opposite side to the utility holders, attach the mat rack connectors to the unit. Press down firmly until the connectors are flush with the bath.

14




Push down on the mat rack connectors to secure.

15




Open the fixing buckles on the change mat. Align the buckles with the mat rack and secure together.

16




Locate the soft straps at the corners of the change mat and insert them into the corresponding slots. Press down on the buckles until they are securely fastened.
WARNING: Ensure soft straps are secured with buckles when the change mat is in use.

17




Align the towel rail with the hooks on the side of the unit.
Push down vertically until it is secure.

18



Remove the towel rail. Align the wash bowl with the hooks on the side of the unit. Push down vertically until it is secure.
Note. the towel rail and wash bowl cannot be installed at the same time.

19



Hang the drainage hose on the side of the wash bowl or the towel rail, whichever you have installed at that time.
WARNING: When using the bath, care should be taken that the water is of a suitably safe temperature before placing the child in.

Warnings

WARNING: Before using, remove and dispose of any plastic bags and other packaging (e.g. fasteners, fixing ties, etc.) and keep them out of reach of children.
WARNING: Do not leave the child unattended.
WARNING: The carer shall at all times be in contact with the child.
WARNING: To avoid drowning; always keep child within arms reach.
WARNING: Children burn easily. Always check the temperature of the water before use.
WARNING: The drainage hose should be permanently attached to the bath drainage outlet or stored out of the reach of children.
WARNING: Drowning can occur in a very short time and in very shallow water. Children have drowned in infant bath tubs. Use of this product does not limit the risk of drowning and a child shall at all times be supervised by a responsible adult.
WARNING: DROWNING HAZARD! Children have drowned while bathing.
WARNING: Children can drown in as little as 2 cm of water in a very short time.
WARNING: Always remain in contact with your child during bathing.
WARNING: Never leave your baby unattended in the bath, even for a few moments. If you need to leave the room, take the baby with you.
WARNING: The changer is suitable for children from birth up to 11kg (approximately 12 months of age).
WARNING: Recommended maximum bath water temperature 37°C. Recommended maximum bath duration 10 minutes.
WARNING: Babies and young children are at risk of drowning when being bathed.
WARNING: Never use this product on an elevated surface not intended for this product.
WARNING: To avoid scalding by hot water, position the product in such a way to prevent the child from reaching the source of water.

Warnings

WARNING: Always check the stability of the product before use.
WARNING: Never use this product on an elevated surface not intended for this product.
WARNING: Always lock the castors when the changer is in use.
WARNING: Do not move the changer whilst the unit is in use.
WARNING: The basket and middle shelf are capable of supporting up to 2kg maximum of goods, evenly distributed on each level.
WARNING: Do not use the changer for a manner it was not designed for.
WARNING: Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the changing unit.
WARNING: The changer must be used on a level and stable surface.
WARNING: This bath tub can be used on the stand up to when the child tries to stand up by itself.
WARNING: Always check the attachment and the stability of the bath tub on the stand.
WARNING: Do not move the changer when in use.
WARNING: Screws shall not be left loose because a child can squeeze parts of the body, or clothing (e.g. strings, necklaces, ribbons for babies, dummies, etc.) could get caught. There would be a danger of strangulation.
WARNING: Do not use the changer if any parts seem to be broken or missing.

Care & Maintenance

The correct use and maintenance of this changer is essential.
Regularly check all parts of the product to ensure that they are operating correctly and for signs of wear or damage.
All assembly fittings shall always be correctly tightened and checked regularly.
Do not use this product if any part is broken, torn or missing and use only spares provided by the manufacturer.

The changer can be cleaned by sponging with warm water.
Stubborn marks can be removed with a non-abrasive cream cleaner.
Never clean with abrasive, ammonia based, bleach or spirit type cleaner.
Ensure the product is fully dry before use or storage.
Always ensure the bath changer is stored in a dry place to prevent mold or mildew developing.

Troubleshooting

Issue	Solution
Unit not stable	Regularly check and tighten all nuts to prevent wobbling or structural failure.
Moving when in use	Ensure all wheels are locked when the unit is in use to prevent movement.
Bath leaking	Check the drainage tube connection and the plug, ensuring the tube is securely attached to the outlet.

For any and all other product issues not covered in the above please contact our dedicated customer services team
Contact: support@pugglebaby.co.uk

Recycling the Packaging

When you have unpacked your product and ensured that all parts are present,
Please discard the packaging components in accordance with your local authority guidelines. For further information, please check the material and your postcode at

https://www.recyclenow.com/recycle-an-item.

Notes

Notes

Notes

www.thenurserystore.co.uk

Imported by Online4baby Ltd.
Meadowbank, Tweedale Way, Oldham, OL9 8EH